


TELECOMMUNICATION CHARGING

ETI 2506

Monday, September 26, 2016





WHY WE NEED A CHARGING PLAN?




1. Providing a telecommunication service **calls for investment in capital items as well as meeting operational expenses.**
2. The **capital cost** includes that of line plant, switching systems, buildings and land.
3. **Operating costs** include staff salaries, maintenance costs, water and electricity and miscellaneous expenses.
4. **A telecommunication administration receives its income from its subscribers.**
5. **A charging plan provides for recovering both the capital costs and the operating costs from subscribers.**

CALCULATING THE COSTS




1. The **cost of shared resources** like the switching equipment is amortised among a large number of subscribers over a period of time.
2. The **cost of dedicated resources** like the telephone instrument and the subscriber line **must be recovered** from individual customers.
3. The **operating costs** must be worked out depending on the quantum of resources used in providing a service and the duration for which these resources are used.




- A telecommunication service can levy three categories of charges to a subscriber:
 1. An initial charge for providing a network connection:
 2. A. rental or leasing charge
 3. Charges for individual calls made.

OTHER CLASSIFICATION



1. **Operating costs** for telephone exchanges and transmission networks.
2. **Government policy** e.g. policy on subsidy of local calls by trunk/international calls, taxes or USO.
3. **Communication regulations**, e.g. CAK's guidelines on interconnection.




1. Duration Independent Charging

- Local calls in the fixed Networks are usually charged on a duration independent-basis.
- The subscriber meter is incremented once at the start of a local call.

2. Duration Dependent Charging


- Periodic pulse train of pulses from a common pulse generator operate the subscribers meter.
- Modern exchanges store date, time and duration in seconds for the purpose of charging.

DISTANCE-RELATED CHARGING




Distance (km)	Metering pulse rate (pulses/min)
20 - 50	1.67
50 - 100	5.00
100 - 200	7.50
200 - 500	15.00
500 - 1000	20.00
> 1000	30.00

TARIFF VARIATION




1. Telephone exchange capacity is based on the estimated capacity at the busy hour.
2. As a result, a large part of the capacity remains idle during off-peak hours.
3. Most operators lower tariffs to encourage subscribers to call at off-peak hours

EXAMPLE OF TARIFF VARIATION SCHEME



Period of day	Metre pulse repetition rate
08.00 hours – 19.00 hours	X
19.00 hours – 22.00 hours	$X/2$
22.00 hours – 06.00 hours	$X/4$
06.00 hours – 08.00 hours	$X/2$

EXAMPLE




A telephone administration provides **leased lines at the rate of Kshs. 600 per km** for a minimum rental period of 3 months. MMU, a point-to-point traffic user, **has offices located 600 km apart and is confronted with the choice of using Subscriber Trunk Dialing (STD) or leased lines.**

At what traffic volume per day, should the organization move from STD to leased line?

- Assume 20 working days per month and a rate of Kshs. 1 per unit recorded by the meter.
- Assume that STD calls are charged at Kshs. 20 per minute.

SOLUTION





1. Cost of renting the leased line is $600 \times 600 = \text{Kshs. } 360,000$
2. Cost of STD calls per hour is $60 \times 20 = \text{Kshs. } 1200$
3. Let the break-even point occur when the STD line is used for x hours in three months. Then we have
$$1200x = 360,000,$$
or
$$x = 300 \text{ hours in 3 months} = 100 \text{ Hours in a Month} = 5 \text{ hours per day}$$

Common Channel Signaling

ETI2506

Monday, 26 September 2016









1. Exchange Hierarchy Classification
 - Subscriber loop signaling
 - Intra-exchange or register signaling
 - Inter-exchange or inter-register signaling.

2. Channel-Level Classification
 - In Channel Signaling
 - Common Channel Signaling


SIGNALING TECHNIQUES




COMMON CHANNEL SIGNALLING



CCS SIGNALLING FRAME FORMAT



COMPARISON OF IN-CHANNEL AND COMMON-CHANNEL



IN-CHANNEL	COMMON-CHANNEL
<ul style="list-style-type: none">• Trunks are held up during signalling	<ul style="list-style-type: none">• Trunks are not required for signaling
<ul style="list-style-type: none">• Interference between Voice and Control Signals may occur	<ul style="list-style-type: none">• No interference since the voice and control channels are separate
<ul style="list-style-type: none">• Separate signaling equipment is required in each trunk hence expensive	<ul style="list-style-type: none">• Only one set of signaling equipment is required for a large group of trunk circuits hence economical
<ul style="list-style-type: none">• Can be misused by customers since it is easy to mimic voice signaling	<ul style="list-style-type: none">• Control channel is in-accessible to users
<ul style="list-style-type: none">• Signalling is relatively slow	<ul style="list-style-type: none">• Signalling is much faster
<ul style="list-style-type: none">• Speech circuit continuity is assured when signaling is received	<ul style="list-style-type: none">• State of speech circuit not automatically assured
<ul style="list-style-type: none">• It is difficult to change or add signals	<ul style="list-style-type: none">• There is flexibility to add or change signals